

Bosky Retail Price List *Spares Issue 11 June 07*

60/65

90/95

		EX VAT & DEL			EX VAT & DEL
1 Left hand side panel S1/S2 (NEW P/N B70006790)	60001868	£105.05			
2 Right hand side panel (NEW P/N B70006791)	60001869	£105.08			
3 Back panel	60001871	£109.69	60001872		£105.51
4 Front loading door knob (NEW P/N B60004321)	60001875	£17.12			
4a Secondary air slide	60002182	£5.87			
5 Front loading door (NEW P/N B70008657)	60001876	£100.41			
6 Front loading door rope 71cm x 9mm soft (SAME P/N)	60001877	£4.64			
7 Plus/minus plate (NEW P/N B60004284)	60001878	£4.63			
8/9 Boiler thermostat securing nut/screw No10x1/2" zinc posi self taper	60001879	£0.78			
10 Boiler thermostat mechanism S1	60001881	£58.85			
10 Boiler thermostat mechanism S2	60001881	£58.85			
11 Boiler thermostat knob (NEW P/N B60005443)	60001882	£9.27			
12 Boiler thermostat lower arm (NO LONGER AVAILABLE) SEE B70006018	60001883	£6.18			
16 Primary air inlet flap sprint = 12,16,17 NOT SOLD SEP £25.00	60001887	£1.54			
17 Primary air inlet flap S1/S2	60001888	£7.73			
12/16/17 NOT SOLD SEPARATE (P/N B70006018F £11.81 + VAT)					
18 Lifting arm/frame connecting bar	60001889	£9.28			
19 Connecting bar securing pin	60001890	£3.09			
20 Ash door spring	60001891	£6.19			
21 Boiler cleaning plate washer		£0.73			
22 Release lever securing pin		£0.73			
23 Grate lifting catch	60001894	£27.81			
24 Lever assembly spacer	60001895	£3.09			
25 Lever assembly connecting bar	60001896	£4.64			
26 2 connecting bar securing pin	60001896A	£3.09			
27 Ducksfoot	60001897	£29.35			
28 Ducksfoot pin	60001898	£6.19			
29 Lifting arm/frame connecting bar	60001899	£35.54	60001900		£38.61
30 Release lever	60001901	£9.27			
31 Release level knob	60001902	£6.18			
33 Boiler thermometer S1 - Round (NEW P/N B60004286)	60001904/A	£27.84			
33 Boiler thermometer S2 -Square (Not available any more round does fit)					
Vertical panel (boiler models only) S1/S2		£79.41			
34 Lever housing clip	60001905	£3.09			
36 Over heat flap knob	60001907	£7.73			

37	Over heat flap spring	60001908	£3.10		
38	Oven heat flap spacer	60001909	£1.54		
39	Oven heat flap position locator	60001910	£7.72		
40	Oven heat flap lever	60001911	£10.82		
41	Grate shift lever knob	60001912	£10.91		
42	Grate shift lever	60001913	£40.17		
43	Ash door hinge pin	60001914	£6.18		
44	Left hand insulation		£7.22		
47	Ash door knob (NEW BOSKY P/N B60004423)	60001918	£18.53		
48	Booster flap	6001919	£8.03		
49	Ash door rope (NEW BOSKY P/N B60010335)		£7.22		
50	Ash door catch and pin	60001924	£6.18		
52	Boiler cleaning plate	60001926	£12.36		
54	Boiler cleaning plate knob/bolt	60001928	£3.10		
55	Lower oven hinge washer		£0.73		
56	Lower over door top strip	60001930	£13.91		
57	Lower oven door handle (NEW BOSKY P/N B6009368 GREY)	60001931	£17.40		
	Lower oven door handle (NEW BOSKY P/N B6004225 BROWN)		£17.40		
58	Lower oven door main body	60001932	£52.53		
59	Lower over door inner face S1/S2	60001933	£43.26		
60	Lower over door hinge (NEW BOSKY P/N B60004182)	60001934	£11.55		
64	Oven cleaning plate (NEW BOSKY P/N B70004138)	60001938	£7.72		
66	Right hand insulation		£7.22		
67	Large glass (NEW BOSKY P/N B60009303)	60001943	£49.43		
68	Oven door panel	60001944	£43.26		
69	Small glass (NEW BOSKY P/N B60010005)	60001945	£27.81		
70	Over thermometer (NEW BOSKY P/N B60009950)	60001946	£7.73		
72	Main oven door hinge catch (NEW BOSKY P/N B60004246)	60001948	£12.36		
74	Main oven hinge (NEW BOSKY P/N B60010170)	60001949	£23.18		
75	Drip tray (NEW BOSKY P/N B7000564)	60001950	£27.82		
76	Oven rack single or twin slide (NEW BOSKY P/N B60004211)	60001951	£32.44		
77	Top rope 60/90	60001952	£23.17		
78	Per metre 12mm	60000013	£10.00		
79	Stainless surround (NEW BOSKY P/N B60004249)	60001953	£126.68	60001954	£131.27
78	Right hand inset plate (NEW BOSKY P/N B70006020)	60001957	£77.86		
80	Oven heat flap (NEW BOSKY P/N B80005359)	60001958	£32.44		
80a	Oven top deflector (L-shaped)	60001958A	£27.81		
	Low point thermostat (anti-con)	60007102	£49.43		
81	Comb grate (NEW BOSKY P/N B80005360)	60001959	£29.35		
83	Direct draft flap S1/S2	60001961	£24.72		
84	Direct draft flap pin		£1.44		

85 Centre plate (state cooker/boiler) (NEW BOSKY P/NB70006039)	60001962	£35.53		
86 Right hand front side grate (NEW BOSKY P/N B80005353)	60001969	£23.17		
90 Blanking plate	60001974	£10.82		
91 Flue spigot (NEW BOSKY P/N B80005348)	60001977	£18.54		
95 Notched side grate (NEW BOSKY P/N B80005352)	60001980	£23.18		
96 Lifting frame (NEW BOSKY P/N B70009811 60/65)	60001982	£69.52	60001984	£75.69
97 Left hand front inset plate (NEW BOSKY P/N 60/65 B60005930)	60002076	£44.79	60002078	£44.79
Left hand front inset plate (NEW BOSKY P/N 90/95b60005932)		£44.80		£44.79
98 Left hand rear inset plate (NEW BOSKY P/N 60/65 B60005931)	60002080	£41.71	60002081	£44.79
Left hand rear inset plate (NEW BOSKY P/N 90/95 B60005933)		£44.80		£44.79
99 Left hand side grate (NEW BOSKY P/N B80005354)	60001992	£23.17		
100 Grate - offset riddling (NO LONGER AVAILABLE)	60000001	£0.00	60000003	£90.95
Grate - centre riddling	60000002	£85.07	60000004	£90.95
100A Italian Spec Grate	80005356	£67.68	80005355	£75.03
Italian Spec Cradle	80005358	£115.35	80005357	£94.16
101 Cradle - offset riddling (B80005358 Not available any more see 100A)	60000005	£138.57	60000007	£122.71
Cradle - centre riddling (B80005357)	60000006	£115.35	60000008	£122.71
102 Lifting tool	60002003	£18.54		
103 Left hand enamel top strip S1/S2		£5.78		
104 Left hand door handle S1/S2 (NEW BOSKY P/N B60009366 GREY 60/65.90/95 IS B60009367)	60002006	£10.81	60002007	£12.36
Left hand door handle S1/S2 (NEW BOSKY P/N B60004223 BROWN 60/65 90/95 IS B60004224)		£10.81		£12.36
105 Door handle bracket - right S1/S2 (NEW BOSKY P/N B60004175)	60002009	£9.28		
106 Left hand door enamel panel S1/S2 (NEW BOSKY P/N B70006778 & 90/95 B70006779)	60002010	£133.75	60002012	£122.04
108 Door catch (male)	60002016	£9.28		
109 Left hand door frame	60002019	£23.50	60002020	£26.26
110 Door handle bracket - left S1/S2 (NEW BOSKY P/N B60004177)	60002008	£9.63		
112 Door loading catch (NEW BOSKY P/N B70005811)	60002026	£13.91		
113 Front loading door catch circlip	60002028	£3.09		
114 Front loading door hinge pin	60002030	£7.72		
117 Door restraining bracket S1/S2	60002040	£7.72		
119 Cleaning tool (NEW BOSKY P/N B60004209)	60002042	£18.54		
120 Over door lower strip	60002044	£7.73		
121 Ash door S1/S2 (NEW BOSKY P/N 60/65 B70008700)	60002045	£115.86	60002047	£73.83
Ash door S1/S2 (NEW BOSKY P/N 90.95 B70008650)		£115.86		£73.83
123 Door catch (female) (NEW BOSKY P/N B60004231)	60002054	£7.72		
124 Ash pan (NEW BOSKY P/N 60/65 B70004376 90/95 IS B70004377)	60002055	£49.43	60002074	£65.97
125 Lower left hand oven inner panel	60002084	£49.43		
126 Lower right hand oven inner panel	60002085	£49.73		
127 Oven vertical grill	60002086	£28.05		
127a Radiation plate	60001984U	£18.54		

128 Electric element (rear) (NEW BOSKY P/N IS THE SAME)	60002087R	£64.88	
128 Electric element (bottom) (NEW BOSKY P/N B60004729)	60002087B	£64.88	
128A Electric element (wiring)	60002087D	£21.96	
128B Electric element (bottom) cover part number is	70009393	£61.74	
129 Electric control panel - only S1/S2	60002088	£27.82	
130 Oven thermostat knob (NEW BOSKY P/N B60004226)	60002089	£9.28	
131 On/off switch (NEW BOSKY P/N B60008121)	60002090	£18.54	
132 Oven thermostat mechanism (NEW BOSKY P/N B60005706)	60002091	£55.61	
133 Oven thermostat limit piece	60002092	£6.19	
135 Insulated cover bracket - left	60002094	£10.82	
135A Insulated cover bracket screw	60002095	£2.44	
136 Cover hinge pin - left (135A,136,137 NOT SOLD SEP)	60002096	£7.75	
137 Side hinge plate	60002096B	£4.64	
138 Cover hinge pin - right	60002102	£7.73	
139 Insulated cover bracket - right	60002105	£10.82	
140 Left hand insulated cover - pair (NEW BOSKY P/N 60/65 B7004481 90/95 B7004482) (NO LONGER ABAILABLE)	60002098A		60002100A
141 Right hand insulated cover (NEW BOSKY P/N B7004480) (NO LONGER AVAILABLE)	60002108		
142 Middle cover knob	60002109	£9.28	
143 Middle cover hinge	60002111	£6.18	
144 Left and right insulated cover handle	60002113	£18.54	
146 Wiring loom - through the oven 60/90	70006036W	£41.17	
Wiring loom - through the oven 65/95	70006037W	£41.71	
Wiring loom - short		£38.98	
Wiring loom - long		£38.98	
147 Electric cable ducting	60002087C	£13.91	
148 Riddling Handle	60002002	£21.63	
200 Flue Box 6"	60000009	£99.88	
200 Flue Box 8"	60000010	£85.00	
220 Ring	60002180	£5.56	
221 Circlip	60002181	£5.07	
222 Complete rope for under hotplate bosky 65/95	600012954	£20.95	

Complete Items

Cooker Insulated covers 60/90 (NO LONGER AVAILABLE)	60002121		60002122	
Boiler insulated covers 65/95 (NO LONGER AVAILABLE)	60002123		60002124	
Left hand enamel door (NEW P/N B70006778 60/65 & 90/95 B70006779)	60002168	£115.86	60002169	£122.04
Main oven door	60002170	£146.76		
Lower oven door (NEW BOSKY P/N B70006780)	60002171	£131.31		
Front loading door (NEW BOSKY P/N B70008657)	60002172	£100.41		
Ash pan door (NEW BOSKY P/N B70008700 60/65)	60002173	£115.86		
Ash pan door (NEW BOSKY P/N B70008650 90/95)	70008650	£73.83		
Electric control panel - cooker (NEW BOSKY P/N B70009037)	70009037	£162.20		

Electric control panel - boiler (NEW BOSKY P/N B70006038)	70006038	£100.41
Over heat flap assembly		£28.89
Zebracier (per tube) (old part no:183701)	60000012	£8.83
Cook tops		£216.57
Boiler Connectors B65/95 (1 1/4)	77-01-735	£5.56
Reducers (1 1/4 to 28mm)	77-01-752	£0.79
Boiler Tapping plugs 60/90	77-01-754	£1.78
Boiler Tapping white end for plugs	60004189F	£1.65
Clip on pipe thermometer	77-01-377	£2.73
New Bosky Poker for italian spec grate	60000011	£29.90
Bosky 60 New Style Top Plate C/W 3 Round Hot Plates	70008703	£220.38
Bosky 90 New Style Top Plate C/W 3 Round Hot Plates	70008671	£239.63
Bosky 65 New Style Top Plate C/W 1 Round Hot Plate	70008823	£135.16
Boaky 95 New Style Top Plate C/W 1 Round Hot Plate	70008827	£149.37